



## Template Boat Steps

---

### **STEP ONE:**

Lay the clear mylar flat on the area where you would like your SleekTEAK. Using masking tape to tape the edges of the mylar ( 4 mil plastic) will help keep the template in place while you are tracing your pattern. It is best to work from one piece of mylar at a time. If needed, you can trim the mylar to fit in a tight or curved area, but do not cut the mylar into the shapes of the parts.

### **STEP TWO:**

Use a black marker (sharpie) to trace your desired pattern. If your boat has a molded in non-skid, use the non-skid edge to trace the parts. If your boat is smooth, trace the parts to the desired size.

### **STEP THREE:**

Note how the parts align by using a straight edge to draw a line from part to part. This will ensure proper orientation for all parts.

### **STEP FOUR:**

For all pieces templated, label the following on each part:

- "Bow" for part orientation
- Cut outs, hinges, or latches
- Number each part
- Notate TOP on the top of each part

### **STEP FIVE:**

If you require digitizing services take photos of your traced pattern on the boat before detaching and email them to [info@savagecanvascompany.com](mailto:info@savagecanvascompany.com)

**Ship Templates to:** Jeff Murray : [\(423\) 253-2244](tel:4232532244)  
Savage Canvas Digitizing  
163 Bank Street Suite, B Tellico Plains, TN 37385

*If a logo is desired, please call in to a representative to verify that we are able to create it. If a text logo is desired, specify the font style you want, as well as the location and size of the logo on the pad. If no text style is selected, we will use a block style generic font.*